

olinkgo note pro

Your smart assistant



User manual

Declaration

The products and information mentioned in this manual are provided for reference only and may be modified without prior notice. The content may be updated at any time.

1. Product Specifications


Parameter	Value
Storage capacity	64 GB
Dimensions	85 x 55 x 3 mm
Internal battery	400mAh
Charging port	Magnetic
Puissance d'entrée	5V --- 0,5A
Operating temperature	-10°C to +55°C

2. Product Overview

The Olinkgo Note Pro can be attached to the back of a phone and used to record anytime, anywhere. Recording starts with a single click. We recommend using the Olinkgo Note Pro with our app, which makes it easy to export, transcribe, and translate your recordings.



Technical Data:



3. Device Buttons

Button/Indicator	Operation	Effect
Power and recording button	Press for 1 second	Powers on when the recorder is off
	Press for 3 seconds	Powers off
	Press for 1 second	Start/stop recording
	Press for 10 seconds	Reset the device in case of malfunction
Slide button	Slide up	Call recording mode
	Slide down	In-person recording mode
Smart screen	Mode	Visual
	In charge	[⚡]
	Battery percentage	[11]
	Low battery	[!]
	Note Mode	[NOTE]
	Call Mode	[CALL]
	Recording in progress	[🎤]
	Logging in	[🔒]
	Offline	[🚫]
	OTA and file transfer	[📶]

4. Connecting to the App


Step 1: Download the Olinkgo Note Pro app

You can scan the QR code below to download the app, or search for “Olinkgo Note Pro” on the App Store or Play Store.




Step 2: Complete your registration and log in to the app.

Step 3 : Tap the “Add” button in the top right corner of the home page, then select “Add a device”. Follow the instructions to complete the network setup process.



Step 4: Allow the app to access Bluetooth and Wi-Fi. After the nearby device search, select your device and wait for the setup to complete. Your device is now ready to use.



5. Precautions

This section is intended to help users operate this voice recorder correctly and ensure optimal performance. Please read it carefully and follow it.

- Do not subject the device to strong impacts.
- Do not expose the device to chemicals such as benzene or thinners.
- Do not place the device near strong magnetic or electric fields.
- Do not immerse the device in water or place it near intense heat sources.
- Do not attempt to disassemble, repair, or modify the device yourself.

6. Built-in Battery Precautions

- Do not disassemble, strike, crush, or throw the battery into fire.
- If the battery swells significantly, stop using it.
- Do not place the battery in a high-temperature environment.
- Do not throw the battery away. To prevent environmental pollution, please recycle it properly.

7. Troubleshooting

If the recorder does not turn on: Check whether the battery is depleted. Connect the device to a computer or charger, then try turning it on again.

If you cannot download your files:

- Check that the computer and recorder are properly connected.
- Check whether the internal memory is full.
- Check whether the USB cable is damaged.

Additional Information

The memory capacity indicated at the factory may vary slightly due to different unit conversion methods. In addition, part of the storage capacity indicated on the device is used for formatting and certain system functions. As a result, the full advertised capacity is not available for data storage. The storage space actually available to the user may therefore be lower than the nominal capacity indicated on the product.

When charging the device with a power adapter, the user must use an adapter that complies with applicable standards.

8. Accessories List

Olinkgo Note Pro	1
User manual	1
Magnetic ring	1
Leather protective case	1
USB-C charging cable	1

9. Warranty Terms

- Your device is covered by a two-year warranty from the purchase date shown on the invoice, for any defect resulting from normal use.
- For any warranty claim, please contact customer service and provide your purchase invoice.
- Keep your invoice in a safe place — it is required for any product replacement.

If you encounter any problem with your device, feel free to contact us at: contact@olinkgo.com.

The following situations are not covered by free repair services:

- Products whose warranty period has expired, or for which no invoice or valid proof of purchase can be provided.
- Products showing normal wear of their appearance due to regular use, when the consumer requests replacement of worn parts or of the entire product.
- Defects or malfunctions resulting from use of the product not in accordance with the instructions in the user manual.
- Products that have undergone overload testing or performance testing as part of a demonstration or trade exhibition.

Names and Content of Hazardous Substances in Products

Part name	Hazardous Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Housing and components	○	○	○	○	○	○
PCBA	○	○	○	○	○	○
Battery	○	○	○	○	○	○
Speaker	○	○	○	○	○	○

This table is prepared in accordance with standard SJ/T11364.

○ Indicates that the hazardous substance content in all homogeneous materials of this component is below the limits specified in standard GB/T 26572.

× Indicates that the hazardous substance content in at least one homogeneous material of this component exceeds the limit specified in standard GB/T 26572. The labeled period corresponds to the period (10 years) during which the hazardous substances contained in electrical and electronic products do not leak or undergo changes under normal conditions of use. During this period, use of the product does not cause serious environmental pollution or significant harm to persons or property.